



Your Bathroom/Ensuite/Cloakroom is fitted with a 3 amp HRC (High Rupture Capacity) fuse over the head of the door way to protect the extract fan as required by the manufacturer. In some instances when a lamp blows in a Track or downlight the current load caused by this lamp failure will cause this protective fuse to blow.

The fuse is the same type as fitted in your plugtops around the house and is rated at 3 amps these fuses are readily available from all DIY stores, Woolworths etc. and is a simple safe DIY procedure to swap over.

Turn off the switch on the unit over the head off the door - with a small bladed screw driver ease the fuse carrier out (some fuse carriers may have a small screw to lock them shut - this will need releasing first - change the fuse - push back in and switch on. Your fan and lights will now be working - remember that the lamp that caused the fuse to blow will still not be working.

technical@rolec.net

www.rolec.net

ROLEC
net